

SELF-STUDY COURSE 3013-G

Vector-Borne Disease Control



4/91:5R

U.S. DEPARTMENT OF HEALTH AND HUMAN SERVICES

PUBLIC HEALTH SERVICE Centers for Disease Control Public Health Practice Program Office Atlanta, Georgia 30333

VECTOR-BORNE DISEASE CONTROL

Self-Study Course 3013-G

LESSON 3: INSECTICIDAL EQUIPMENT

I: LESSON CONSISTS OF:

Part I: 25 multiple choice questions

Part II: 25 true-false questions

II: REFERENCE:

Insecticide application equipment for the control of insects of public health importance.

III: TOPICS AND READING ASSIGNMENTS:

IOP.	CO AND READING ADDIGUAGE.	Appplication Equipment
A.	Introduction	1
В.	Methods of Applying Insecticides	1
C.	Selection of Insecticide Application Equipment	1- 2
D.	Hand Sprayers	3-14
E.	Hand Dusters	15-18
F.	Power Sprayers	19-20
G.	Power Dusters	20-21
н.	Mist and Fog Applicators	22-23
I.	Mist and Dust Blowers	24-25
	Fog Generators	26-29
	Ultra-Low-Volume Applications	30-35
J.	Other Application Equipment	36
к.	The Relationship between Insecticidal Application and Particle Size	37-43
L.	Care and Maintenance of Insecticidal Equipment	44

VECTOR-BORNE DISEASE CONTROL

Lesson 3 - Objectives

Upon successful completion of Lesson 3, the student should be able to correctly:

- Identify appropriate procedures for the selection of insecticide application equipment, methods of applying insecticides, and maintenance of applicator equipment.
- Identify the component parts of selected insecticide application equipment, the functions of each part, and their relative importance in delivering correct amounts of insecticidal formulations.

VECTOR-BORNE DISEASE CONTROL

LESSON 3: INSECTICIDAL EQUIPMENT

Part I: Multiple Choice

- 1. Insecticides can be applied as:
 - A. Liquids.
 - B. Aerosols.
 - C. Solids.
 - D. All of the above.
- 2. Solid formulations can be applied as:
 - A. Granules.
 - B. Dusts.
 - C. Pellets.
 - D. All of the above.
 - 3. Which of the following is considered to be the mainstay of most insect control projects?
 - A. Hand pump atomizer
 - B. Aerosol dispenser
 - C. Compressed air sprayer
 - D. Pistol sprayer
 - 4. The compressed air sprayer consists of a tank and all of the following <u>EXCEPT</u>:
 - A. An agitator.
 - B. A valve, wand, and nozzle.
 - C. An air pump.
 - D. A spray hose.
 - 5. The air pump of the compressed air sprayer is made up of:
 - A. A handle and a rod.
 - B. A piston and a piston cup.
 - C. A cylinder and a check valve.
 - D. All of the above.
 - 6. Natural rubber should not be used as parts of sprayers because:
 - A. It is difficult to obtain and is too expensive.
 - B. It is disintegrated by the action of some spray solvents.
 - C. It is too flexible.
 - D. It is difficult to clean.

- 7. The most important part of the sprayer is the:
 - A. Agitator.
 - B. Nozzle.
 - C. Air pump.
 - D. Spray hose.
- 8. The primary function(s) of the nozzle on a sprayer is (are):
 - A. To cut the insecticide stream on and off.
 - B. To obtain uniform distribution of insecticides.
 - C. To permit air to be pumped into the sprayer.
 - D. All of the above.
- 9. The delivery rate of a sprayer depends upon:
 - A. The tank pressure and the size of the aperture of the tip.
 - B. The concentration of insecticide.
 - C. The weight of oil used.
 - D. The distance the nozzle is held from the surface being sprayed.
- 10. Teejet nozzles are rated according to:
 - A. The angle of the spray as it leaves the nozzle, and the output in tenths of gallons per minute at 40 psi.
 - B. The size of the nozzle and the angle covered by the spray as it leaves the nozzle.
 - C. The type of whorl chamber and the size of the spray particles.
 - D. The size of the nozzle, and the output, in tenths of gallons per minute, at 40 psi.
- 11. A number 8002 Teejet nozzle produces:
 - A. A solid spray pattern, 0° angle, at 0.2 gallons per minute.
 - B. A flat spray pattern, 80° angle, at 0.20 gallons per minute.
 - C. A flat spray pattern, 50° angle, at 0.4 gallons per minute.
 - D. A hollow cone spray pattern, 80° angle, at 0.15 gallons per minute.
- 12. A number 5004 Teejet nozzle is used for:
 - A. Residual spraying on very smooth surfaces.
 - B. Residual spraying on ordinary surfaces.
 - C. Residual spraying on porous surfaces.
 - D. Mosquito larviciding.
- 13. The pattern of the sprayed insecticide depends primarily on:
 - A. The type of nozzle used.
 - B. The pressure in the sprayer tank.
 - C. The size of the tank.
 - D. The area being sprayed.

- 14. At the start of a spraying operation, the tank of a compressed air sprayer should be:
 - A. One-fourth full of spray liquid.
 - B. One-half full of spray liquid.
 - C. Two-thirds to three-fourths full of spray liquid.
 - D. Entirely full with spray liquid.
- 15. At the start of a spraying operation, the compressed air sprayer should have a tank pressure of approximately:
 - A. 20 psi.
 - B. 30 psi.
 - C. 45 psi.
 - D. 55 psi.
- 16. The Multeejet nozzle has:
 - A. 3 openings.
 - B. 4 openings.
 - C. 5 openings.
 - D. 6 openings.
- 17. A number 8002 Teejet nozzle should not be closer to the surface being sprayed than:
 - A. 18 inches.
 - B. 20 inches.
 - C. 24 inches.
 - D. 30 inches.
- 18. A fog or mist must be dispensed:
 - A. Upwind.
 - B. Crosswind.
 - C. Downwind.
 - D. Only in very still air.
- 19. Which of the following is NOT true regarding mist and fog applicators?
 - A. Their operation is economical because of low manpower requirements.
 - B. They allow the application of small amounts of concentrated insecticide to large areas.
 - C. They are complex in design and require frequent servicing.
 - D. They are high volume, enabling the quick treatment of large portions of a city during disasters and in periods of high insect abundance.

- 20. Particle size produced by mist machines can be varied by:
 - A. Increasing or decreasing air velocity.
 - B. Using fine or coarse spray nozzles.
 - C. Light or heavy spray oil.
 - D. All of the above.
- 21. The optimum particle size of an aerosol effective against adult mosquitoes and flies is:
 - A. 200 400 microns.
 - B. 100 200 microns.
 - C. 50 100 microns.
 - D. 10 50 microns.
- 22. The correct amount of malathion to apply in aerial ULV application is:
 - A. 2 oz. per acre.
 - B. 3 oz. per acre.
 - C. 4 oz. per acre.
 - D. 5 oz. per acre.
- 23. If a vehicle moves at a speed of five miles per hour and a mist or fog applicator lays down a 50 foot wide swath, how many acres per hour will be covered?
 - A. 10 acres per hour.
 - B. 20 acres per hour.
 - C. 30 acres per hour.
 - D. 40 acres per hour.
- 24. If an insecticide application machine travels one mile and has an effective swath width of 200 feet, how many acres will be treated?
 - A. 25 acres
 - B. 50 acres
 - C. 75 acres
 - D. 100 acres
- 25. Basic rules to be followed in the care of a sprayer include which of the following?
 - A. Strain formulations through cheesecloth to keep particles out.
 - B. Rinse the sprayer thoroughly after every use.
 - C. Do not let water freeze in the sprayer.
 - D. All of the above.

Part II: True-False - Mark "A" for True, "D" for False.

- Tanks of compressed air sprayers are constructed of stainless steel, brass, or galvanized steel.
- Stainless steel used in tanks of compressed air sprayer is not corrosion resistant.
- If a compressed air sprayer is not provided with an air release, it is advisable to turn the tank upside down and release the air through the spray gun.
- 4. The solid-stream nozzle applies a fine jet of insecticide to treat cracks and crevices for the control of cockroaches, ants, etc.
- The flat-spray nozzle is used chiefly for residual applications of insecticides.
- 6. The hollow-cone nozzle should be used exclusively for fly larviciding.
- 7. A Teejet nozzle number 5004 has four different apertures.
- 8. Teejet nozzle number 8002 will deposit 200 milligrams of insecticide per square foot, when surfaces are being treated at a rate of 190 sq. ft. per minute with a 2.5 percent solution of insecticide.
- 9. The hand pump atomizer uses a piston pump to force air over the upper end of a small tube. This draws the insecticide from a tank attached to the pump, and breaks the liquid up into droplets.
- The pistol sprayer produces a fine mist of insecticide when the trigger is pulled.
- Hand shakers are hopeless for putting insecticidal dusts on difficult-to-reach areas.
- 12. The hand bellows is excellent for applying dusts indoors where careful placement and neatness are essential.
- Rotary dusters are used effectively for applying insecticidal dusts for controlling fleas, ticks, and other ectoparasites around homes.
- 14. Power sprayers of 50- to 150-gallon capacity are suitable for extensive application of a residual insecticide to fences, porches, and out buildings.
- Mist applicators are designed to apply a residual deposit of insecticides over large areas.

- Fog generators depend upon favorable air currents for distribution of the insecticide.
- 17. A mist is composed of fine particles (average diameter 40 microns) that will remain suspended for a long period of time.
- 18. Mist blowers use a large air fan to produce a column of wind into which liquid insecticide is injected.
- 19. Oil solutions must be used in thermal fog generators.
- Ultra-low-volume spraying is defined as the application of technical grade insecticide at a rate not to exceed two quarts per acre.
- Recommended dosages of technical grade insecticide for adult mosquito control using the ULV aerosol method are 0.5 oz. of malathion, or 3 oz. of naled, per acre.
- 22. Paint brushes are especially suited to household insect control.
- Dichlorvos resin strips give effective control of household insects for about a year.
- 24. In actual practice, people who apply insecticides outdoors figure that one acre is approximately 8 feet wide and 1 mile (5280 feet) long.
- 25. Sprayers are easier to maintain than dusters.

DHHS:PHS:CDC:PHPPO Division of Media and Training Services

(FOR TRAINING PURPOSES ONLY)

4/91:5R

NAME	
MAILING ADDRESS:	
N N	

CDC
LESSON
3

SELF-STUDY COURSE 3013-G Vector-Borne Disease Control

ANSWER SHEET

PART I		T	PART	11
NO.	ABCD	NO.	Α	D
1	0 0 0 0	1	0	0
2	0000	2	0	0
3	0000	3	0	0
4	0 0 0 0	4	0	0
5	0000	5	0	0
6	0000	6	0	0
7	0000	7	0	0
8	0000	8	0	0
9	0000	9	0	0
10	0000	10	0	0
11	0000	11	0	0
12	0000	12	0	0
13	0000	13	0	0
14	0000	14	0	0
15	0000	15	0	0
16	0000	16	0	0
17	0 0 0 0	17	0	0
18	0 0 0 0	18	0	0
19	0000	19	0	0
20	0 0 0 0	20	0	0
21	0 0 0 0	21	0	0
22	0 0 0 0	22	0	0
23	0 0 0 0	23	0	0
24	0 0 0 0	24	0	0
25	0000	25	0	0